Analysis and Exploration of Proteomics Data

R Markdown

This is an R Markdown document. Markdown is a simple formatting syntax for authoring HTML, PDF, and MS Word documents. For more details on using R Markdown see http://rmarkdown.rstudio.com.

Proteomics Data Analysis

Below are shown the steps typically used to transform, process and analyze proteomics data. The analysis steps have been applied over the *EGF-driven protein synthesis* case-study data from D.A. Rothenberg et al. A Proteomics Approach to Profiling the Temporal Translational Response to Stress and Growth. iScience. 2018; 9:367-381.

We mainly rely DEP R-package (Zhang et.al.) for integrated analysis workflow for robust and reproducible analysis of mass spectrometry proteomics data for differential protein expression or differential enrichment.

Loading of R-Packages

We start by loading the R-packages we need to use for our analysis:

```
library("DEP")
library("readr")
library("vsn")
library("dplyr")
library("tidyr")
library("limma")
library("ggplot2")
library("ggrepel")
library("knitr")
library("tidyverse")
```

Loading of the data and initial processing

We load the raw protein intensities:

```
data <- read.delim("../Data/protein intensities.txt")</pre>
colnames (data)
##
    [1] "Gene"
                        "Accession"
                                       "Sequence"
                                                       "PBS 30 Rep1"
                                                                       "PBS 60 Rep1"
##
   [6] "PBS_90_Rep1"
                        "PBS_120_Rep1" "PBS_150_Rep1" "EGF_30_Rep1"
                                                                       "EGF_60_Rep1"
## [11] "EGF 90 Rep1"
                        "EGF 120 Rep1" "EGF 150 Rep1" "PBS 30 Rep2"
                                                                       "PBS 60 Rep2"
## [16] "PBS_90_Rep2"
                                                                       "EGF_60_Rep2"
                        "PBS_120_Rep2" "PBS_150_Rep2" "EGF_30_Rep2"
  [21] "EGF_90_Rep2"
                        "EGF_120_Rep2" "EGF_150_Rep2" "PBS_30_Rep3"
                                                                       "PBS_60_Rep3"
  [26] "PBS_90_Rep3"
                        "PBS_120_Rep3" "PBS_150_Rep3" "EGF_30_Rep3"
                                                                       "EGF_60_Rep3"
  [31] "EGF_90_Rep3"
                        "EGF_120_Rep3" "EGF_150_Rep3" "PBS_30_Rep4"
                                                                       "PBS 60 Rep4"
                        "PBS_120_Rep4" "PBS_150_Rep4"
  [36] "PBS_90_Rep4"
                                                       "EGF_30_Rep4"
                                                                       "EGF_60_Rep4"
  [41] "EGF_90_Rep4"
                        "EGF_120_Rep4" "EGF_150_Rep4"
head(data)
```

Sequence PBS_30_Rep1 PBS_60_Rep1

```
HSPE1 CH10 HUMAN
                                               GGEIQPVSVK
                                                                 98880
                                                                             133900
## 2 HSPE1
             CH10 HUMAN
                                          VLQATVVAVGSGSK
                                                                215980
                                                                             282280
## 3 EFTUD2 U5S1 HUMAN
                                           IAVEPVNPSELPK
                                                                              37250
                                                                 20970
      YWHAB 1433B HUMAN
                                                                157680
                                                                             215370
                                                   SELVQK
      YWHAB 1433B HUMAN TAFDEAIAELDTLNEESYKDSTLIMQLLR
                                                                 44780
                                                                               65620
      YWHAB 1433B HUMAN
                                             YLSEVASGDNK
                                                                 42580
                                                                               57410
     PBS 90 Rep1 PBS 120 Rep1 PBS 150 Rep1 EGF 30 Rep1 EGF 60 Rep1 EGF 90 Rep1
                                       147600
## 1
           92870
                         111600
                                                    132300
                                                                 190600
                                                                              104200
## 2
           190020
                         220860
                                       258580
                                                    261080
                                                                 354470
                                                                              234470
## 3
           22680
                          27430
                                        33200
                                                     29590
                                                                  45670
                                                                               32610
## 4
           172330
                         178840
                                       232800
                                                    172670
                                                                 250300
                                                                              168350
## 5
                          54980
                                        71120
                                                                               56390
           46350
                                                     46100
                                                                  84290
                          50640
## 6
                                                                                50310
            44390
                                        56210
                                                     44140
                                                                  75060
##
     EGF_120_Rep1 EGF_150_Rep1 PBS_30_Rep2 PBS_60_Rep2 PBS_90_Rep2 PBS_120_Rep2
## 1
            137000
                          138900
                                           NA
                                                        NA
                                                                      NA
## 2
            273450
                          298530
                                           NA
                                                        NA
                                                                      NA
                                                                                    NA
## 3
             36300
                           45390
                                        71200
                                                     72900
                                                                  84900
                                                                                 75100
## 4
                                                                                    NA
            213260
                          225100
                                           NA
                                                        NA
                                                                      NA
## 5
             67730
                           81740
                                           NA
                                                        NA
                                                                      NA
                                                                                    NA
## 6
                           55100
                                           NA
                                                                      NA
                                                                                    NA
             50150
                                                        NA
##
     PBS_150_Rep2 EGF_30_Rep2 EGF_60_Rep2 EGF_90_Rep2 EGF_120_Rep2 EGF_150_Rep2
## 1
                NA
                             NA
                                          NA
                                                       NA
                                                                      NA
## 2
                                          NA
                                                                      NA
                NA
                             NA
                                                       NA
                                                                                    NA
## 3
                                       85300
                                                   104000
                                                                 108000
                                                                                 85000
             76400
                          85800
                                                                                    NA
## 4
                NA
                             NA
                                          NA
                                                       NA
                                                                      NA
## 5
                NA
                             NA
                                          NA
                                                       NA
                                                                      NA
                                                                                    NA
## 6
                NA
                             NA
                                          NA
                                                       ΝA
                                                                      NA
                                                                                    NA
     PBS_30_Rep3 PBS_60_Rep3 PBS_90_Rep3 PBS_120_Rep3 PBS_150_Rep3 EGF_30_Rep3
## 1
                            NA
                                                       NA
                                                                      NA
               NA
                                         NA
                                                                                   NA
## 2
               NA
                            NA
                                         NA
                                                       NA
                                                                      NA
                                                                                   NA
## 3
               NA
                            NA
                                         NA
                                                       NA
                                                                      NA
                                                                                   NA
## 4
               NA
                            NΑ
                                         NA
                                                       NA
                                                                      NA
                                                                                   NA
## 5
               NA
                            NA
                                         NA
                                                       NA
                                                                      NA
                                                                                   NA
## 6
               NA
                            NA
                                         NA
                                                       NA
                                                                      NA
                                                                                   NA
     EGF 60 Rep3 EGF 90 Rep3 EGF 120 Rep3 EGF 150 Rep3 PBS 30 Rep4 PBS 60 Rep4
##
## 1
               NA
                            NA
                                          NA
                                                        NA
                                                                 637000
                                                                              787000
## 2
                            NA
                                          NA
               NA
                                                        NA
                                                                 142000
                                                                              171000
## 3
               NA
                            NΑ
                                          NA
                                                        NA
                                                                 214000
                                                                               266000
                            NA
                                          NA
## 4
               NA
                                                        NA
                                                                      NA
                                                                                   NA
## 5
               NA
                            NA
                                          NA
                                                        NA
                                                                  23000
                                                                                29900
                            NA
## 6
               NA
                                          NA
                                                        NA
                                                                     NA
                                                                                   NA
##
     PBS_90_Rep4 PBS_120_Rep4 PBS_150_Rep4 EGF_30_Rep4 EGF_60_Rep4 EGF_90_Rep4
## 1
          644000
                         858000
                                      1090000
                                                    792000
                                                                 981000
                                                                              994000
## 2
           158000
                         194000
                                       213000
                                                    167000
                                                                 208000
                                                                              189000
## 3
           234000
                         264000
                                       319000
                                                    255000
                                                                 305000
                                                                              266000
## 4
               NA
                                                                                   NA
                             NA
                                           NA
                                                        NA
                                                                      NA
## 5
            29500
                          21700
                                        36600
                                                     30900
                                                                  35400
                                                                                31200
## 6
               NA
                             NA
                                           NA
                                                        NA
                                                                      NA
                                                                                   NA
     EGF_120_Rep4 EGF_150_Rep4
## 1
          1060000
                          961000
## 2
           211000
                          168000
## 3
            297000
                          252000
## 4
                NA
                              NA
## 5
             28100
                           28800
```

```
## 6 NA NA
```

We then search for duplicated protein identifiers on the data table (Accession ID), summarize them and then we make unique names using the annotation in the "Accession" column as primary names and the annotation in "Sequence" as to identify for individual quantified peptide sequences.

```
# Are there any duplicated protein names?
data$Accession %>% duplicated() %>% any()

## [1] TRUE

# Make a table of duplicated protein names
data %>% group_by(Accession) %>% summarize(frequency = n()) %>%
    arrange(desc(frequency)) %>% filter(frequency > 1)
```

```
## # A tibble: 949 x 2
##
      Accession
                  frequency
##
      <chr>
                       <int>
    1 PLEC_HUMAN
##
                         115
##
    2 AHNK_HUMAN
                          86
    3 FLNA_HUMAN
                          59
##
    4 MYH9_HUMAN
                          52
##
##
    5 FLNB HUMAN
                          44
##
    6 TLN1_HUMAN
                          43
##
    7 VINC HUMAN
                          34
    8 MUC16_HUMAN
                          32
##
    9 FAS HUMAN
                          31
##
## 10 KI67_HUMAN
## # ... with 939 more rows
```

Make unique names using the annotation in the "Accession" and "Sequence" column.
data_unique <- make_unique(data, "Accession", "Sequence", delim = ";")
head(data_unique)</pre>

##		Gene Acc	ession		Sequence	PBS_30_Rep1 1	PBS_60_Rep1
##	1	HSPE1 CH10	_HUMAN		GGEIQPVSVK	98880	133900
##	2	HSPE1 CH10	_HUMAN	VLQ.	ATVVAVGSGSK	215980	282280
##	3	EFTUD2 U5S1	_HUMAN	IA	VEPVNPSELPK	20970	37250
##	4	YWHAB 1433B	_HUMAN		SELVQK	157680	215370
##	5	YWHAB 1433B	_HUMAN TAFDEA	IAELDTLNEESY	KDSTLIMQLLR	44780	65620
##	6	YWHAB 1433B	_HUMAN		YLSEVASGDNK	42580	57410
##		PBS_90_Rep1	PBS_120_Rep1	PBS_150_Rep1	EGF_30_Rep1	EGF_60_Rep1	EGF_90_Rep1
##	1	92870	111600	147600	132300	190600	104200
##	2	190020	220860	258580	261080	354470	234470
##	3	22680	27430	33200	29590	45670	32610
##	4	172330	178840	232800	172670	250300	168350
##	5	46350	54980	71120	46100	84290	56390
##	6	44390	50640	56210	44140	75060	50310
##		EGF_120_Rep1	EGF_150_Rep1	PBS_30_Rep2	PBS_60_Rep2	PBS_90_Rep2	PBS_120_Rep2
##	1	137000	138900	NA NA	NA	. NA	NA
##	2	273450	298530	NA NA	NA	. NA	NA
##	3	36300	45390	71200	72900	84900	75100
##	4	213260	225100	NA NA	NA	. NA	NA
##	5	67730	81740	NA NA	NA	. NA	NA
##	6	50150	55100	NA NA	NA	. NA	NA
##		PBS_150_Rep2	EGF_30_Rep2	EGF_60_Rep2	EGF_90_Rep2	EGF_120_Rep2	EGF_150_Rep2
##	1	NA	NA	NA	NA	NA	NA

```
## 2
                              NA
                                           NA
                                                                       NA
                                                                                      NA
                NA
                                                         NA
## 3
             76400
                           85800
                                        85300
                                                    104000
                                                                   108000
                                                                                   85000
## 4
                NA
                              NA
                                           NA
                                                         NA
                                                                       NA
                                                                                      NA
## 5
                NA
                              NA
                                           NA
                                                         NA
                                                                       NA
                                                                                      NA
##
                NA
                              NA
                                           NA
                                                         NA
                                                                       NA
                                                                                      NA
     PBS_30_Rep3 PBS_60_Rep3 PBS_90_Rep3 PBS_120_Rep3 PBS_150_Rep3 EGF_30_Rep3
##
## 1
               NA
                             NA
                                          NA
                                                         NA
                                                                       NA
                                                                                     NA
## 2
               NA
                             NA
                                          NA
                                                         NA
                                                                       NA
                                                                                     NA
## 3
               NA
                             NA
                                          NA
                                                         NA
                                                                       NA
                                                                                     NA
## 4
                             NA
                                          NA
               NA
                                                         NA
                                                                       NA
                                                                                     NA
## 5
               NA
                             NA
                                          NA
                                                         NA
                                                                       NA
                                                                                     NA
## 6
               NA
                             NA
                                          NA
                                                         NA
                                                                       NA
                                                                                     NA
##
     EGF_60_Rep3
                  EGF_90_Rep3
                                EGF_120_Rep3
                                              EGF_150_Rep3 PBS_30_Rep4 PBS_60_Rep4
                                                                                787000
## 1
               NΑ
                             NA
                                           ΝA
                                                          NA
                                                                   637000
## 2
                                           NA
               NA
                             NA
                                                          NA
                                                                   142000
                                                                                171000
## 3
               NA
                             NA
                                           NA
                                                          NA
                                                                   214000
                                                                                266000
## 4
               NA
                             NA
                                           NA
                                                          NA
                                                                       NA
                                                                                     NA
## 5
               NA
                             NA
                                           NA
                                                          NA
                                                                    23000
                                                                                 29900
## 6
                             NA
                                                                                     NA
               NA
                                           NA
                                                          NA
                                                                       NA
##
     PBS_90_Rep4 PBS_120_Rep4 PBS_150_Rep4 EGF_30_Rep4 EGF_60_Rep4 EGF_90_Rep4
## 1
           644000
                         858000
                                       1090000
                                                     792000
                                                                   981000
                                                                                994000
## 2
           158000
                         194000
                                        213000
                                                     167000
                                                                   208000
                                                                                189000
## 3
           234000
                                                     255000
                                                                   305000
                                                                                266000
                         264000
                                        319000
## 4
               NA
                              NA
                                             NA
                                                          NA
                                                                       NA
                                                                                     NA
## 5
            29500
                                                       30900
                                                                                 31200
                           21700
                                         36600
                                                                    35400
## 6
               NA
                              NA
                                            NA
                                                          NA
                                                                       NA
                                                                                     NA
##
     EGF_120_Rep4 EGF_150_Rep4
                                                                                ID
                                            name
                                                                       GGEIQPVSVK
## 1
           1060000
                           961000
                                      CH10_HUMAN
## 2
            211000
                           168000
                                   CH10_HUMAN.1
                                                                   VLQATVVAVGSGSK
## 3
            297000
                           252000
                                      U5S1_HUMAN
                                                                    IAVEPVNPSELPK
## 4
                                     1433B_HUMAN
                                                                            SELVQK
## 5
             28100
                           28800 1433B_HUMAN.1 TAFDEAIAELDTLNEESYKDSTLIMQLLR
## 6
                NA
                               NA 1433B_HUMAN.2
                                                                      YLSEVASGDNK
# Are there any duplicated names?
```

data\$name %>% duplicated() %>% any()

[1] FALSE

Experimental Design

We make an experimental design matrix where we indicate the condition and replicate ID's for each sample.

```
# We show the sample ID's
labels <- colnames(data_unique)[4:43]
print(labels)</pre>
```

```
##
    [1] "PBS 30 Rep1"
                        "PBS 60 Rep1"
                                        "PBS 90 Rep1"
                                                        "PBS 120 Rep1" "PBS 150 Rep1"
##
    [6] "EGF 30 Rep1"
                        "EGF 60 Rep1"
                                        "EGF 90 Rep1"
                                                        "EGF 120 Rep1" "EGF 150 Rep1"
  [11] "PBS_30_Rep2"
                        "PBS_60_Rep2"
                                        "PBS_90_Rep2"
                                                        "PBS_120_Rep2" "PBS_150_Rep2"
   [16]
       "EGF_30_Rep2"
                        "EGF_60_Rep2"
                                        "EGF_90_Rep2"
                                                        "EGF_120_Rep2" "EGF_150_Rep2"
   [21]
        "PBS_30_Rep3"
                        "PBS_60_Rep3"
                                        "PBS_90_Rep3"
                                                        "PBS_120_Rep3" "PBS_150_Rep3"
##
                                                        "EGF_120_Rep3" "EGF_150_Rep3"
   [26]
        "EGF_30_Rep3"
                        "EGF_60_Rep3"
                                        "EGF_90_Rep3"
   [31]
       "PBS_30_Rep4"
                        "PBS_60_Rep4"
                                        "PBS_90_Rep4"
                                                        "PBS_120_Rep4" "PBS_150_Rep4"
## [36] "EGF_30_Rep4"
                                                        "EGF_120_Rep4" "EGF_150_Rep4"
                        "EGF_60_Rep4"
                                        "EGF_90_Rep4"
```

```
# We setup the experimental design matrix
experimental_design <- matrix(data = , nrow = length(labels), ncol = 3)</pre>
experimental design[, 1] <- labels</pre>
experimental_design[, 2] <- sapply(strsplit(x = labels, split = "_Rep", fixed = TRUE), "[", 1)</pre>
experimental_design[, 3] <- sapply(strsplit(x = labels, split = "_", fixed = TRUE), "[", 3)
colnames(experimental_design) <- c("label", "condition", "replicate")</pre>
experimental_design <- as.data.frame(experimental_design)</pre>
print(experimental_design)
##
             label condition replicate
## 1
       PBS 30 Rep1
                      PBS_30
                                   Rep1
## 2
       PBS_60_Rep1
                      PBS_60
                                   Rep1
## 3
       PBS_90_Rep1
                      PBS_90
                                   Rep1
      PBS_120_Rep1
                      PBS_120
## 4
                                   Rep1
## 5
      PBS_150_Rep1
                      PBS_150
                                   Rep1
                      EGF_30
       EGF_30_Rep1
## 6
                                   Rep1
                      EGF_60
## 7
       EGF_60_Rep1
                                   Rep1
## 8
       EGF_90_Rep1
                      EGF_90
                                   Rep1
## 9
      EGF_120_Rep1
                      EGF_120
                                   Rep1
                      EGF_150
## 10 EGF_150_Rep1
                                   Rep1
      PBS 30 Rep2
                      PBS 30
                                   Rep2
## 11
                      PBS 60
## 12
      PBS 60 Rep2
                                   Rep2
## 13 PBS_90_Rep2
                      PBS 90
                                   Rep2
## 14 PBS 120 Rep2
                      PBS 120
                                   Rep2
                      PBS_150
## 15 PBS_150_Rep2
                                   Rep2
                      EGF_30
## 16
      EGF_30_Rep2
                                   Rep2
                      EGF_60
## 17
       EGF_60_Rep2
                                   Rep2
## 18 EGF_90_Rep2
                      EGF 90
                                   Rep2
## 19 EGF_120_Rep2
                      EGF_120
                                   Rep2
## 20 EGF_150_Rep2
                      EGF_150
                                   Rep2
                      PBS_30
## 21
      PBS_30_Rep3
                                   Rep3
                      PBS_60
## 22
      PBS_60_Rep3
                                   Rep3
                      PBS_90
## 23
      PBS_90_Rep3
                                   Rep3
## 24 PBS_120_Rep3
                      PBS_120
                                   Rep3
## 25 PBS_150_Rep3
                      PBS_150
                                   Rep3
## 26
      EGF_30_Rep3
                      EGF_30
                                   Rep3
                      EGF_60
       EGF_60_Rep3
                                   Rep3
## 27
## 28 EGF_90_Rep3
                      EGF_90
                                   Rep3
## 29 EGF 120 Rep3
                      EGF 120
                                   Rep3
                      EGF_150
## 30 EGF_150_Rep3
                                   Rep3
## 31
      PBS 30 Rep4
                      PBS 30
                                   Rep4
                      PBS_60
## 32 PBS_60_Rep4
                                   Rep4
## 33 PBS_90_Rep4
                      PBS_90
                                   Rep4
```

Data Processing

34 PBS_120_Rep4

35 PBS_150_Rep4

39 EGF_120_Rep4

40 EGF_150_Rep4

EGF_30_Rep4

EGF_60_Rep4

EGF_90_Rep4

36

37

38

PBS_120

PBS 150

EGF_30

EGF_60

EGF_90

EGF_120

EGF_150

Rep4

Rep4

Rep4

Rep4

Rep4

Rep4

Rep4

Summarize Data We summarize the raw data into an object format recognizable by the *DEP* R-package.

```
# Generate a SummarizedExperiment object using an experimental design
Int_columns <- 4:43 # get Intensity column numbers
data_se <- make_se(data_unique, Int_columns, as.data.frame(experimental_design))
data_se

## class: SummarizedExperiment
## dim: 5669 40
## metadata(0):
## assays(1): ''
## rownames(5669): CH10_HUMAN CH10_HUMAN.1 ... TRUA_HUMAN RTCB_HUMAN
## rowData names(5): Gene Accession Sequence name ID
## colnames(40): PBS_30_Rep1 PBS_60_Rep1 ... EGF_120_Rep4 EGF_150_Rep4
## colData names(4): label ID condition replicate
```

Filtering We filter the proteomics dataset based on missing values. The dataset is filtered for proteins that have a maximum of 2 missing values in at least one condition.

Filter for proteins that are identified in 2 out of 4 replicates of at least one condition

```
data_filt <- filter_missval(data_se, thr = 2)
data_filt


## class: SummarizedExperiment
## dim: 2108 40
## metadata(0):
## assays(1): ''
## rownames(2108): 1433B_HUMAN.1 1433E_HUMAN ... ZFR_HUMAN.4 ZN622_HUMAN.2
## rowData names(5): Gene Accession Sequence name ID
## colnames(40): PBS_30_Rep1 PBS_60_Rep1 ... EGF_120_Rep4 EGF_150_Rep4</pre>
```

Normalization We perform a variance stabilizing transformation/normalization using the vsn-package. We then also see the differences in the data before and after normalization.

colData names(4): label ID condition replicate

```
# Normalize the data
data_norm <- normalize_vsn(data_filt)

# Visualize normalization by boxplots for all samples before and after normalization
plot_normalization(data_filt, data_norm)</pre>
```




Imputation There are still many missing values in the data. We perform **imputation** in order to impute missing values in the data-set.

```
# Percentage of missing data
perc <- length(which(is.na(data_norm@assays@data@listData[[1]])))/(dim(data_norm@assays@data@listData[[
print(pasteO(round(x = 100*perc, digits = 2), "%"))

FALSE [1] "38.21%"
# Impute missing data using random draws from a Gaussian distribution centered around a minimal value (
data_imp <- impute(data_norm, fun = "MinProb", q = 0.01)</pre>
FALSE [1] 0.8196504
```


Interpretation We perform a dimensionality reduction/PCA analysis in order to enhance the interprability of the data by reducing it's complexity.

```
matrix_data <- data_imp@assays@data@listData[[1]]</pre>
# PCA plot based on condition
groups <- experimental_design$condition</pre>
names(groups) <- experimental_design$label</pre>
data.pca <- t(matrix_data)</pre>
data.pca <- cbind(data.pca, as.matrix(groups))</pre>
colnames(data.pca)[ncol(data.pca)] <- "Group"</pre>
data.pca <- as.data.frame(data.pca)</pre>
data.pca[, 1:(ncol(data.pca)-1)] <- lapply(data.pca[, 1:(ncol(data.pca)-1)],</pre>
                                             function(x) as.numeric(as.character(x)))
res.pca <- prcomp(data.pca[, -ncol(data.pca)], scale. = TRUE)</pre>
res.plot <- as.data.frame(cbind(res.pca$x[, 1], res.pca$x[, 2],</pre>
                                   as.character(data.pca$Group), rownames(data.pca)))
res.plot[, 1:2] <- lapply(res.plot[, 1:2], function(x) as.numeric(as.character(x)))
res.plot[, 3:4] <- lapply(res.plot[, 3:4], function(x) as.character(x))</pre>
colnames(res.plot) <- c("pc1", "pc2", "Group", "sample")</pre>
percentages <- ((res.pca$sdev)^2 / sum(res.pca$sdev^2)*100)[1:2]</pre>
pp <- ggplot(res.plot, aes(x=pc1, y=pc2, color=Group)) +
  geom_point(size=7, alpha = 0.5) +
  scale_alpha_discrete(range=c(0.3, 1.0)) +
  theme minimal() +
  xlab(paste0("PC1 (", round(x = percentages[1], digits = 2), "%)")) +
  ylab(paste0("PC2 (", round(x = percentages[2], digits = 2), "%)")) +
  xlim(c(-max(abs(res.pca$x[, 1])), max(abs(res.pca$x[, 1])))) +
  ylim(c(-max(abs(res.pca$x[, 2])), max(abs(res.pca$x[, 2])))) +
  theme(legend.position = "none") +
  geom_text_repel(data = res.plot, aes(label=sample), max.overlaps = 100)
plot(pp)
```




```
# PCA plot based on relpicate
groups <- experimental_design$replicate</pre>
names(groups) <- experimental_design$label</pre>
data.pca <- t(matrix_data)</pre>
data.pca <- cbind(data.pca, as.matrix(groups))</pre>
colnames(data.pca)[ncol(data.pca)] <- "Group"</pre>
data.pca <- as.data.frame(data.pca)</pre>
data.pca[, 1:(ncol(data.pca)-1)] <- lapply(data.pca[, 1:(ncol(data.pca)-1)],</pre>
                                               function(x) as.numeric(as.character(x)))
res.pca <- prcomp(data.pca[, -ncol(data.pca)], scale. = TRUE)</pre>
res.plot <- as.data.frame(cbind(res.pca$x[, 1], res.pca$x[, 2],</pre>
                                    as.character(data.pca$Group), rownames(data.pca)))
res.plot[, 1:2] <- lapply(res.plot[, 1:2], function(x) as.numeric(as.character(x)))</pre>
res.plot[, 3:4] <- lapply(res.plot[, 3:4], function(x) as.character(x))
colnames(res.plot) <- c("pc1", "pc2", "Group", "sample")</pre>
percentages <- ((res.pca$sdev)^2 / sum(res.pca$sdev^2)*100)[1:2]</pre>
```

```
pp <- ggplot(res.plot, aes(x=pc1, y=pc2, color=Group)) +
   geom_point(size=7, alpha = 0.5) +
   scale_alpha_discrete(range=c(0.3, 1.0)) +
   theme_minimal() +
   xlab(paste0("PC1 (", round(x = percentages[1], digits = 2), "%)")) +
   ylab(paste0("PC2 (", round(x = percentages[2], digits = 2), "%)")) +
   xlim(c(-max(abs(res.pca$x[, 1])),max(abs(res.pca$x[, 1])))) +
   ylim(c(-max(abs(res.pca$x[, 2])),max(abs(res.pca$x[, 2])))) +
   theme(legend.position = "none") +
   geom_text_repel(data = res.plot, aes(label=sample), max.overlaps = 100)
   plot(pp)</pre>
```



Batch Effect Removal There are **Batch Effects** across replicates which we need to remove. We remove the batch effects through the *removeBatchEffect()* function of the *limma* R-package. Next we verify the removal of batch effects with a **PCA** plot of the transformed data.


```
# Remove Batch effects
batch_rem <- removeBatchEffect(x = matrix_data, batch = experimental_design$replicate)</pre>
# PCA plot based on condition after removing the batch effects
groups <- experimental design$condition</pre>
names(groups) <- experimental_design$label</pre>
data.pca <- t(batch_rem)</pre>
data.pca <- cbind(data.pca, as.matrix(groups))</pre>
colnames(data.pca)[ncol(data.pca)] <- "Group"</pre>
data.pca <- as.data.frame(data.pca)</pre>
data.pca[, 1:(ncol(data.pca)-1)] <- lapply(data.pca[, 1:(ncol(data.pca)-1)],</pre>
                                                                                                     function(x) as.numeric(as.character(x)))
res.pca <- prcomp(data.pca[, -ncol(data.pca)], scale. = TRUE)</pre>
res.plot <- as.data.frame(cbind(res.pca$x[, 1], res.pca$x[, 2],
                                                                              as.character(data.pca$Group), rownames(data.pca)))
res.plot[, 1:2] <- lapply(res.plot[, 1:2], function(x) as.numeric(as.character(x)))</pre>
res.plot[, 3:4] <- lapply(res.plot[, 3:4], function(x) as.character(x))</pre>
colnames(res.plot) <- c("pc1", "pc2", "Group", "sample")</pre>
percentages <- ((res.pca$sdev)^2 / sum(res.pca$sdev^2)*100)[1:2]</pre>
pp <- ggplot(res.plot, aes(x=pc1, y=pc2, color=Group)) +</pre>
     geom_point(size=7, alpha = 0.5) +
     scale_alpha_discrete(range=c(0.3, 1.0)) +
     #geom_path(arrow=arrow()) +
     theme_minimal() +
     xlab(paste0("PC1 (", round(x = percentages[1], digits = 2), "%)")) +
     varphi(x) = varp
     xlim(c(-max(abs(res.pca$x[, 1])), max(abs(res.pca$x[, 1])))) +
     ylim(c(-max(abs(res.pca$x[, 2])), max(abs(res.pca$x[, 2])))) +
     theme(legend.position = "none") +
     geom_text_repel(data = res.plot, aes(label=sample), max.overlaps = 100)
plot(pp)
```



We create the *DEP Object* after removing the batch effects and **comparing the distribution** of data before and after batch effect removal.

```
# Create the DEP object after removing the batch effects
data_batch <- data_imp
data_batch@assays@data@listData[[1]] <- batch_rem

# Plot intensity distributions before and after batch correction
plot_normalization(data_imp, data_batch)</pre>
```



Differential Analysis

We perform **Differential Analysis** in order to identify the differentially abundant Proteins.

```
# Test manually defined comparisons for time-point 60.
data_diff_manual <- test_diff(data_batch, type = "manual",</pre>
                              test = c("EGF_60_vs_PBS_60"))
ttop <- as.data.frame(data_diff_manual@elementMetadata)</pre>
ttop <- ttop[, c(1:4, 10:12)]
head(ttop)
FALSE
                 name Gene
                              Accession
                                                              Sequence
FALSE 1 1433B HUMAN.1 YWHAB 1433B HUMAN TAFDEAIAELDTLNEESYKDSTLIMQLLR
FALSE 2 1433E_HUMAN YWHAE 1433E_HUMAN
                                                          EAAENSLVAYK
FALSE 3 1433E_HUMAN.1 YWHAE 1433E_HUMAN
                                                         VAGMDVELTVEER
FALSE 4 1433G HUMAN YWHAG 1433G HUMAN
                                                             ATVVESSEK
FALSE 5 1433G HUMAN.1 YWHAG 1433G HUMAN
                                                       NVTELNEPLSNEER
FALSE 6 1433G_HUMAN.2 YWHAG 1433G_HUMAN
                                                            YLAEVATGEK
FALSE EGF_60_vs_PBS_60_diff EGF_60_vs_PBS_60_p.adj EGF_60_vs_PBS_60_p.val
                  -0.04039041
                                           0.9941130
FALSE 1
                                                                  0.89289459
FALSE 2
                  -0.16835928
                                           0.9925200
                                                                  0.67059127
FALSE 3
                  -0.60650337
                                           0.9646068
                                                                  0.09962624
FALSE 4
                   0.24352346
                                           0.9905036
                                                                  0.50171574
FALSE 5
                  -0.36229264
                                           0.9755310
                                                                  0.15673519
FALSE 6
                  -0.23820613
                                           0.9922571
                                                                  0.64316536
ttop$expression = ifelse(ttop$EGF_60_vs_PBS_60_p.val < 0.05 & abs(ttop$EGF_60_vs_PBS_60_diff) >= 1,
                     ifelse(ttop$EGF_60_vs_PBS_60_diff> 1 ,'Up','Down'),
                     'Stable')
ttop$label <- NA
ttop$label[which(ttop$expression!="Stable")] <- ttop$Gene[which(ttop$expression!="Stable")]
p <- ggplot(data=ttop, aes(x=EGF_60_vs_PBS_60_diff, y=-log10(EGF_60_vs_PBS_60_p.val), col=expression, l
  geom_point() +
  theme minimal() +
  geom_text_repel() +
  scale_color_manual(values=c("blue", "black", "red")) +
  geom_vline(xintercept=c(-0.6, 0.6), col="red") +
  geom_hline(yintercept=-log10(0.05), col="red") +
  labs(x="log2(fold change)",
       y="-log10 (p-value)",
       title="Differential Protein Abundance")
p
```

